



PRODUCT-DETAILS

3ADT313900R1501  
SDCS-CON-4-COAT-ROHS; SDCS-CON-4 COAT-ROHS CONTROL BOARD



概要信息	
产品ID	3ADT313900R1501
ABB型号名称	SDCS-CON-4-COAT-ROHS
目录说明	SDCS-CON-4-COAT-ROHS; SDCS-CON-4 COAT-ROHS CONTROL BOARD

附加信息	
ABB型号名称	SDCS-CON-4-COAT-ROHS
CN8	85371098
核心信用	0.00
原产地	China Hong Kong Special Administrative Region of China
海关关税号	85371098
外形尺寸	Spare_Parts
毛重	0.399 kg
发票说明	SDCS-CON-4 COAT-ROHS CONTROL BOARD
按订单生产	否
最小起订量	1 piece
订单倍数	1 piece

1级包装 总重	0.399 kg
1级包装单元	1 piece
部件类型	New
产品	SDCS-CON-4 COAT-ROHS CONTROL BO
产品净重	0.52 kg
产品应用类型	Spare_Parts
仅报价	否
更换产品ID（OLD）	3ADT313900R1001
销售度量单位	piece
仓库库存	Finland Menden, Germany New Berlin,Wisconsin, United States Beijing, China Singapore, Singapore Tokyo, Japan Finland Bangalore, India
技术信息	Control board deliveries include always the latest firmware.Current ve rsion is 80x3.70. Please pay attentionon the compatibilities descrped in the folder PICTURE
WEEE 类别	Product Not in WEEE Scope

用在哪里			
Identifier	Description	Quantity	Unit Of Measure
DCS800-S01-0020-04	No Description Available	1	piece
DCS800-S01-0020-05	No Description Available	1	piece
DCS800-S01-0045-04	No Description Available	1	piece
DCS800-S01-0045-05	No Description Available	1	piece
DCS800-S01-0065-04	No Description Available	1	piece
DCS800-S01-0065-05	No Description Available	1	piece
DCS800-S01-0090-04	No Description Available	1	piece
DCS800-S01-0090-05	No Description Available	1	piece
DCS800-S01-0125-04	No Description Available	1	piece
DCS800-S01-0125-05	No Description Available	1	piece
DCS800-S01-0180-04	No Description Available	1	piece
DCS800-S01-0180-05	No Description Available	1	piece
DCS800-S01-0230-04	No Description Available	1	piece
DCS800-S01-0230-05	No Description Available	1	piece
DCS800-S01-0290-06	No Description Available	1	piece
DCS800-S01-0315-04	No Description Available	1	piece
DCS800-S01-0315-05	No Description Available	1	piece
DCS800-S01-0405-04	No Description Available	1	piece
DCS800-S01-0405-05	No Description Available	1	piece
DCS800-S01-0470-04	No Description Available	1	piece
DCS800-S01-0470-05	No Description Available	1	piece
DCS800-S01-0590-06	No Description Available	1	piece
DCS800-S01-0610-04	No Description Available	1	piece
DCS800-S01-0610-05	No Description Available	1	piece

DCS800-S01-0740-04	No Description Available	1	piece
DCS800-S01-0740-05	No Description Available	1	piece
DCS800-S01-0900-04	No Description Available	1	piece
DCS800-S01-0900-05	No Description Available	1	piece
DCS800-S01-0900-06	No Description Available	1	piece
DCS800-S01-0900-07	No Description Available	1	piece
DCS800-S01-1200-04	No Description Available	1	piece
DCS800-S01-1200-05	No Description Available	1	piece
DCS800-S01-1500-04	No Description Available	1	piece
DCS800-S01-1500-05	No Description Available	1	piece
DCS800-S01-1500-06	No Description Available	1	piece
DCS800-S01-1500-07	No Description Available	1	piece
DCS800-S01-1900-08	No Description Available	1	piece
DCS800-S01-2000-04	No Description Available	1	piece
DCS800-S01-2000-05	No Description Available	1	piece
DCS800-S01-2000-06	No Description Available	1	piece
DCS800-S01-2000-07	No Description Available	1	piece
DCS800-S01-2050-05	No Description Available	1	piece
DCS800-S01-2050-06	No Description Available	1	piece
DCS800-S01-2050-07	No Description Available	1	piece
DCS800-S01-2500-04	No Description Available	1	piece
DCS800-S01-2500-05	No Description Available	1	piece
DCS800-S01-2500-06	No Description Available	1	piece
DCS800-S01-2500-07	No Description Available	1	piece
DCS800-S01-2500-08	No Description Available	1	piece
DCS800-S01-3000-04	No Description Available	1	piece
DCS800-S01-3000-05	No Description Available	1	piece
DCS800-S01-3000-06	No Description Available	1	piece
DCS800-S01-3000-07	No Description Available	1	piece
DCS800-S01-3000-08	No Description Available	1	piece
DCS800-S02-0025-04	No Description Available	1	piece
DCS800-S02-0025-05	No Description Available	1	piece
DCS800-S02-0050-04	No Description Available	1	piece
DCS800-S02-0050-05	No Description Available	1	piece
DCS800-S02-0075-04	No Description Available	1	piece
DCS800-S02-0075-05	No Description Available	1	piece
DCS800-S02-0100-04	No Description Available	1	piece
DCS800-S02-0100-05	No Description Available	1	piece
DCS800-S02-0140-04	No Description Available	1	piece
DCS800-S02-0140-05	No Description Available	1	piece
DCS800-S02-0200-04	No Description Available	1	piece
DCS800-S02-0200-05	No Description Available	1	piece
DCS800-S02-0260-04	No Description Available	1	piece
DCS800-S02-0260-05	No Description Available	1	piece
DCS800-S02-0320-06	No Description Available	1	piece
DCS800-S02-0350-04	No Description Available	1	piece
DCS800-S02-0350-05	No Description Available	1	piece
DCS800-S02-0450-04	No Description Available	1	piece
DCS800-S02-0450-05	No Description Available	1	piece
DCS800-S02-0520-04	No Description Available	1	piece
DCS800-S02-0520-05	No Description Available	1	piece
DCS800-S02-0650-06	No Description Available	1	piece
DCS800-S02-0680-04	No Description Available	1	piece
DCS800-S02-0680-05	No Description Available	1	piece

DCS800-S02-0820-04	No Description Available	1	piece
DCS800-S02-0820-05	No Description Available	1	piece
DCS800-S02-1000-04	No Description Available	1	piece
DCS800-S02-1000-05	No Description Available	1	piece
DCS800-S02-0900-06	No Description Available	1	piece
DCS800-S02-0900-07	No Description Available	1	piece
DCS800-S02-1200-04	No Description Available	1	piece
DCS800-S02-1200-05	No Description Available	1	piece
DCS800-S02-1500-04	No Description Available	1	piece
DCS800-S02-1500-05	No Description Available	1	piece
DCS800-S02-1500-06	No Description Available	1	piece
DCS800-S02-1500-07	No Description Available	1	piece
DCS800-S02-1900-08	No Description Available	1	piece
DCS800-S02-2000-04	No Description Available	1	piece
DCS800-S02-2000-05	No Description Available	1	piece
DCS800-S02-2050-05	No Description Available	1	piece
DCS800-S02-2050-06	No Description Available	1	piece
DCS800-S02-2050-07	No Description Available	1	piece
DCS800-S02-2500-04	No Description Available	1	piece
DCS800-S02-2500-05	No Description Available	1	piece
DCS800-S02-2500-06	No Description Available	1	piece
DCS800-S02-2500-07	No Description Available	1	piece
DCS800-S02-2500-08	No Description Available	1	piece
DCS800-S02-3000-04	No Description Available	1	piece
DCS800-S02-3000-05	No Description Available	1	piece
DCS800-S02-3000-06	No Description Available	1	piece
DCS800-S02-3000-07	No Description Available	1	piece
DCS800-S02-3000-08	No Description Available	1	piece
DCS800-S01-2050-10R	No Description Available	1	piece
DCS800-S01-2600-10R	No Description Available	1	piece
DCS800-S01-3300-04R	No Description Available	1	piece
DCS800-S01-3300-05R	No Description Available	1	piece
DCS800-S01-3300-06R	No Description Available	1	piece
DCS800-S01-3300-07R	No Description Available	1	piece
DCS800-S01-3300-08R	No Description Available	1	piece
DCS800-S01-3300-10R	No Description Available	1	piece
DCS800-S01-4000-04R	No Description Available	1	piece
DCS800-S01-4000-05R	No Description Available	1	piece
DCS800-S01-4000-06R	No Description Available	1	piece
DCS800-S01-4000-07R	No Description Available	1	piece
DCS800-S01-4000-08R	No Description Available	1	piece
DCS800-S01-4000-10R	No Description Available	1	piece
DCS800-S01-4800-06R	No Description Available	1	piece
DCS800-S01-4800-07R	No Description Available	1	piece
DCS800-S01-4800-08R	No Description Available	1	piece
DCS800-S01-5200-04R	No Description Available	1	piece
DCS800-S01-5200-05R	No Description Available	1	piece
DCS800-S02-2050-10R	No Description Available	1	piece
DCS800-S02-2600-10R	No Description Available	1	piece
DCS800-S02-3300-04R	No Description Available	1	piece
DCS800-S02-3300-05R	No Description Available	1	piece
DCS800-S02-3300-06R	No Description Available	1	piece
DCS800-S02-3300-07R	No Description Available	1	piece
DCS800-S02-3300-08R	No Description Available	1	piece

DCS800-S02-3300-10R	No Description Available	1	piece
DCS800-S02-4000-04R	No Description Available	1	piece
DCS800-S02-4000-05R	No Description Available	1	piece
DCS800-S02-4000-06R	No Description Available	1	piece
DCS800-S02-4000-07R	No Description Available	1	piece
DCS800-S02-4000-08R	No Description Available	1	piece
DCS800-S02-4000-10R	No Description Available	1	piece
DCS800-S02-4800-06R	No Description Available	1	piece
DCS800-S02-4800-07R	No Description Available	1	piece
DCS800-S02-4800-08R	No Description Available	1	piece
DCS800-S02-5200-04R	No Description Available	1	piece
DCS800-S02-5200-05R	No Description Available	1	piece
DCS800-S01-2050-10L	No Description Available	1	piece
DCS800-S01-2600-10L	No Description Available	1	piece
DCS800-S01-3300-04L	No Description Available	1	piece
DCS800-S01-3300-05L	No Description Available	1	piece
DCS800-S01-3300-06L	No Description Available	1	piece
DCS800-S01-3300-07L	No Description Available	1	piece
DCS800-S01-3300-08L	No Description Available	1	piece
DCS800-S01-3300-10L	No Description Available	1	piece
DCS800-S01-4000-04L	No Description Available	1	piece
DCS800-S01-4000-05L	No Description Available	1	piece
DCS800-S01-4000-06L	No Description Available	1	piece
DCS800-S01-4000-07L	No Description Available	1	piece
DCS800-S01-4000-08L	No Description Available	1	piece
DCS800-S01-4000-10L	No Description Available	1	piece
DCS800-S01-4800-06L	No Description Available	1	piece
DCS800-S01-4800-07L	No Description Available	1	piece
DCS800-S01-4800-08L	No Description Available	1	piece
DCS800-S01-5200-04L	No Description Available	1	piece
DCS800-S01-5200-05L	No Description Available	1	piece
DCS800-S02-2050-10L	No Description Available	1	piece
DCS800-S02-2600-10L	No Description Available	1	piece
DCS800-S02-3300-04L	No Description Available	1	piece
DCS800-S02-3300-05L	No Description Available	1	piece
DCS800-S02-3300-06L	No Description Available	1	piece
DCS800-S02-3300-07L	No Description Available	1	piece
DCS800-S02-3300-08L	No Description Available	1	piece
DCS800-S02-3300-10L	No Description Available	1	piece
DCS800-S02-4000-04L	No Description Available	1	piece
DCS800-S02-4000-05L	No Description Available	1	piece
DCS800-S02-4000-06L	No Description Available	1	piece
DCS800-S02-4000-07L	No Description Available	1	piece
DCS800-S02-4000-08L	No Description Available	1	piece
DCS800-S02-4000-10L	No Description Available	1	piece
DCS800-S02-4800-06L	No Description Available	1	piece
DCS800-S02-4800-07L	No Description Available	1	piece
DCS800-S02-4800-08L	No Description Available	1	piece
DCS800-S02-5200-04L	No Description Available	1	piece
DCS800-S02-5200-05L	No Description Available	1	piece
DCS800-S01-0900-06a	No Description Available	1	piece
DCS800-S01-0900-06-b	No Description Available	1	piece
DCS800-S01-0900-07a	No Description Available	1	piece
DCS800-S01-0900-07-b	No Description Available	1	piece

DCS800-S01-1190-04	No Description Available	1	piece
DCS800-S01-1190-05	No Description Available	1	piece
DCS800-S01-1200-04a	No Description Available	1	piece
DCS800-S01-1200-04-b	No Description Available	1	piece
DCS800-S01-1200-05a	No Description Available	1	piece
DCS800-S01-1200-05-b	No Description Available	1	piece
DCS800-S01-1500-04-b	No Description Available	1	piece
DCS800-S01-1500-05-b	No Description Available	1	piece
DCS800-S01-1500-06-b	No Description Available	1	piece
DCS800-S01-1500-07-b	No Description Available	1	piece
DCS800-S01-1900-08a	No Description Available	1	piece
DCS800-S01-1900-08-b	No Description Available	1	piece
DCS800-S01-2000-04-b	No Description Available	1	piece
DCS800-S01-2000-05-b	No Description Available	1	piece
DCS800-S01-2000-06-b	No Description Available	1	piece
DCS800-S01-2000-07-b	No Description Available	1	piece
DCS800-S01-2050-05a	No Description Available	1	piece
DCS800-S01-2050-05-b	No Description Available	1	piece
DCS800-S01-2050-06a	No Description Available	1	piece
DCS800-S01-2050-06-b	No Description Available	1	piece
DCS800-S01-2050-07a	No Description Available	1	piece
DCS800-S01-2050-07-b	No Description Available	1	piece
DCS800-S01-2050-10-b	No Description Available	1	piece
DCS800-S01-2500-04-b	No Description Available	1	piece
DCS800-S01-2500-05-b	No Description Available	1	piece
DCS800-S01-2500-06-b	No Description Available	1	piece
DCS800-S01-2500-07-b	No Description Available	1	piece
DCS800-S01-2500-08-b	No Description Available	1	piece
DCS800-S01-2600-10-b	No Description Available	1	piece
DCS800-S01-3000-04-b	No Description Available	1	piece
DCS800-S01-3000-05-b	No Description Available	1	piece
DCS800-S01-3000-06-b	No Description Available	1	piece
DCS800-S01-3000-07-b	No Description Available	1	piece
DCS800-S01-3000-08-b	No Description Available	1	piece
DCS800-S01-3300-04-b	No Description Available	1	piece
DCS800-S01-3300-05-b	No Description Available	1	piece
DCS800-S01-3300-06-b	No Description Available	1	piece
DCS800-S01-3300-07-b	No Description Available	1	piece
DCS800-S01-3300-08-b	No Description Available	1	piece
DCS800-S01-3300-10-b	No Description Available	1	piece
DCS800-S01-4000-04-b	No Description Available	1	piece
DCS800-S01-4000-05-b	No Description Available	1	piece
DCS800-S01-4000-06-b	No Description Available	1	piece
DCS800-S01-4000-07-b	No Description Available	1	piece
DCS800-S01-4000-08-b	No Description Available	1	piece
DCS800-S01-4000-10-b	No Description Available	1	piece
DCS800-S01-4800-06-b	No Description Available	1	piece
DCS800-S01-4800-07-b	No Description Available	1	piece
DCS800-S01-4800-08-b	No Description Available	1	piece
DCS800-S01-5200-04-b	No Description Available	1	piece
DCS800-S01-5200-05-b	No Description Available	1	piece
DCS800-S02-0650-07	No Description Available	1	piece
DCS800-S02-0900-06a	No Description Available	1	piece
DCS800-S02-0900-06-b	No Description Available	1	piece

DCS800-S02-0900-07a	No Description Available	1	piece
DCS800-S02-0900-07-b	No Description Available	1	piece
DCS800-S02-1190-04	No Description Available	1	piece
DCS800-S02-1190-05	No Description Available	1	piece
DCS800-S02-1200-04a	No Description Available	1	piece
DCS800-S02-1200-04-b	No Description Available	1	piece
DCS800-S02-1200-05a	No Description Available	1	piece
DCS800-S02-1200-05-b	No Description Available	1	piece
DCS800-S02-1500-04-b	No Description Available	1	piece
DCS800-S02-1500-05-b	No Description Available	1	piece
DCS800-S02-1500-06-b	No Description Available	1	piece
DCS800-S02-1500-07-b	No Description Available	1	piece
DCS800-S02-1900-08a	No Description Available	1	piece
DCS800-S02-1900-08-b	No Description Available	1	piece
DCS800-S02-2000-04-b	No Description Available	1	piece
DCS800-S02-2000-05-b	No Description Available	1	piece
DCS800-S02-2050-05a	No Description Available	1	piece
DCS800-S02-2050-05-b	No Description Available	1	piece
DCS800-S02-2050-06a	No Description Available	1	piece
DCS800-S02-2050-06-b	No Description Available	1	piece
DCS800-S02-2050-07a	No Description Available	1	piece
DCS800-S02-2050-07-b	No Description Available	1	piece
DCS800-S02-2050-10-b	No Description Available	1	piece
DCS800-S02-2500-04-b	No Description Available	1	piece
DCS800-S02-2500-05-b	No Description Available	1	piece
DCS800-S02-2500-06-b	No Description Available	1	piece
DCS800-S02-2500-07-b	No Description Available	1	piece
DCS800-S02-2500-08-b	No Description Available	1	piece
DCS800-S02-2600-10-b	No Description Available	1	piece
DCS800-S02-3000-04-b	No Description Available	1	piece
DCS800-S02-3000-05-b	No Description Available	1	piece
DCS800-S02-3000-06-b	No Description Available	1	piece
DCS800-S02-3000-07-b	No Description Available	1	piece
DCS800-S02-3000-08-b	No Description Available	1	piece
DCS800-S02-3300-04-b	No Description Available	1	piece
DCS800-S02-3300-05-b	No Description Available	1	piece
DCS800-S02-3300-06-b	No Description Available	1	piece
DCS800-S02-3300-07-b	No Description Available	1	piece
DCS800-S02-3300-08-b	No Description Available	1	piece
DCS800-S02-3300-10-b	No Description Available	1	piece
DCS800-S02-4000-04-b	No Description Available	1	piece
DCS800-S02-4000-05-b	No Description Available	1	piece
DCS800-S02-4000-06-b	No Description Available	1	piece
DCS800-S02-4000-07-b	No Description Available	1	piece
DCS800-S02-4000-08-b	No Description Available	1	piece
DCS800-S02-4000-10-b	No Description Available	1	piece
DCS800-S02-4800-06-b	No Description Available	1	piece
DCS800-S02-4800-07-b	No Description Available	1	piece
DCS800-S02-4800-08-b	No Description Available	1	piece
DCS800-S02-5200-04-b	No Description Available	1	piece
DCS800-S02-5200-05-b	No Description Available	1	piece

### Product specific part data

[illegible]



Product	Category	品名
DCS800-S01-3000-04	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S01-3000-05	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S01-3000-06	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S01-3000-07	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S01-3000-08	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-0025-04	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-0025-05	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-0050-04	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-0050-05	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-0075-04	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-0075-05	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-0100-04	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-0100-05	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-0140-04	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-0140-05	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-0200-04	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-0200-05	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-0260-04	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-0260-05	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-0320-06	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-0350-04	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-0350-05	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-0450-04	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-0450-05	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-0520-04	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-0520-05	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-0650-06	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-0680-04	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-0680-05	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-0820-04		Boards, Control Units, Power Supplies
DCS800-S02-0820-05	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-1000-04	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-1000-05	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-0900-06	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-0900-07	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-1200-04	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-1200-05	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-1500-04	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-1500-05	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-1500-06	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-1500-07	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-1900-08	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-2000-04	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-2000-05	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-2050-05	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-2050-06	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-2050-07	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-2500-04	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-2500-05	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-2500-06	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-2500-07	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-2500-08	DCS800-S 30000	Boards, Control Units, Power Supplies
DCS800-S02-3000-04	DCS800-S 30000	Boards, Control Units, Power Supplies

Product	Category	品名
DCS800-S02-3000-05	DCS800-S 300005	Boards, Control Units, Power Supplies
DCS800-S02-3000-06	DCS800-S 300006	Boards, Control Units, Power Supplies
DCS800-S02-3000-07	DCS800-S 300007	Boards, Control Units, Power Supplies
DCS800-S02-3000-08	DCS800-S 300008	Boards, Control Units, Power Supplies
DCS800-S01-2050-10R	DCS800-S 205010	Boards, Control Units, Power Supplies
DCS800-S01-2600-10R	DCS800-S 260010	Boards, Control Units, Power Supplies
DCS800-S01-3300-04R	DCS800-S 330004	Boards, Control Units, Power Supplies
DCS800-S01-3300-05R	DCS800-S 330005	Boards, Control Units, Power Supplies
DCS800-S01-3300-06R	DCS800-S 330006	Boards, Control Units, Power Supplies
DCS800-S01-3300-07R	DCS800-S 330007	Boards, Control Units, Power Supplies
DCS800-S01-3300-08R	DCS800-S 330008	Boards, Control Units, Power Supplies
DCS800-S01-3300-10R	DCS800-S 330010	Boards, Control Units, Power Supplies
DCS800-S01-4000-04R	DCS800-S 400004	Boards, Control Units, Power Supplies
DCS800-S01-4000-05R	DCS800-S 400005	Boards, Control Units, Power Supplies
DCS800-S01-4000-06R	DCS800-S 400006	Boards, Control Units, Power Supplies
DCS800-S01-4000-07R	DCS800-S 400007	Boards, Control Units, Power Supplies
DCS800-S01-4000-08R	DCS800-S 400008	Boards, Control Units, Power Supplies
DCS800-S01-4000-10R	DCS800-S 400010	Boards, Control Units, Power Supplies
DCS800-S01-4800-06R	DCS800-S 480006	Boards, Control Units, Power Supplies
DCS800-S01-4800-07R	DCS800-S 480007	Boards, Control Units, Power Supplies
DCS800-S01-4800-08R	DCS800-S 480008	Boards, Control Units, Power Supplies
DCS800-S01-5200-04R	DCS800-S 520004	Boards, Control Units, Power Supplies
DCS800-S01-5200-05R	DCS800-S 520005	Boards, Control Units, Power Supplies
DCS800-S02-2050-10R	DCS800-S 205010	Boards, Control Units, Power Supplies
DCS800-S02-2600-10R	DCS800-S 260010	Boards, Control Units, Power Supplies
DCS800-S02-3300-04R	DCS800-S 330004	Boards, Control Units, Power Supplies
DCS800-S02-3300-05R	DCS800-S 330005	Boards, Control Units, Power Supplies
DCS800-S02-3300-06R	DCS800-S 330006	Boards, Control Units, Power Supplies
DCS800-S02-3300-07R	DCS800-S 330007	Boards, Control Units, Power Supplies
DCS800-S02-3300-08R	DCS800-S 330008	Boards, Control Units, Power Supplies
DCS800-S02-3300-10R	DCS800-S 330010	Boards, Control Units, Power Supplies
DCS800-S02-4000-04R	DCS800-S 400004	Boards, Control Units, Power Supplies
DCS800-S02-4000-05R	DCS800-S 400005	Boards, Control Units, Power Supplies
DCS800-S02-4000-06R	DCS800-S 400006	Boards, Control Units, Power Supplies
DCS800-S02-4000-07R	DCS800-S 400007	Boards, Control Units, Power Supplies
DCS800-S02-4000-08R	DCS800-S 400008	Boards, Control Units, Power Supplies
DCS800-S02-4000-10R	DCS800-S 400010	Boards, Control Units, Power Supplies
DCS800-S02-4800-06R	DCS800-S 480006	Boards, Control Units, Power Supplies
DCS800-S02-4800-07R	DCS800-S 480007	Boards, Control Units, Power Supplies
DCS800-S02-4800-08R	DCS800-S 480008	Boards, Control Units, Power Supplies
DCS800-S02-5200-04R	DCS800-S 520004	Boards, Control Units, Power Supplies
DCS800-S02-5200-05R	DCS800-S 520005	Boards, Control Units, Power Supplies
DCS800-S01-2050-10L	DCS800-S 205010	Boards, Control Units, Power Supplies
DCS800-S01-2600-10L	DCS800-S 260010	Boards, Control Units, Power Supplies
DCS800-S01-3300-04L	DCS800-S 330004	Boards, Control Units, Power Supplies
DCS800-S01-3300-05L	DCS800-S 330005	Boards, Control Units, Power Supplies
DCS800-S01-3300-06L	DCS800-S 330006	Boards, Control Units, Power Supplies
DCS800-S01-3300-07L	DCS800-S 330007	Boards, Control Units, Power Supplies
DCS800-S01-3300-08L	DCS800-S 330008	Boards, Control Units, Power Supplies
DCS800-S01-3300-10L	DCS800-S 330010	Boards, Control Units, Power Supplies
DCS800-S01-4000-04L	DCS800-S 400004	Boards, Control Units, Power Supplies
DCS800-S01-4000-05L	DCS800-S 400005	Boards, Control Units, Power Supplies
DCS800-S01-4000-06L	DCS800-S 400006	Boards, Control Units, Power Supplies

Product	Category	品名
DCS800-S01-4000-07L	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-4000-08L	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-4000-10L	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-4800-06L	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-4800-07L	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-4800-08L	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-5200-04L	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-5200-05L	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S02-2050-10L		Boards, Control Units, Power Supplies
DCS800-S02-2600-10L	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S02-3300-04L	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S02-3300-05L	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S02-3300-06L	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S02-3300-07L	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S02-3300-08L	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S02-3300-10L	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S02-4000-04L	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S02-4000-05L	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S02-4000-06L	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S02-4000-07L	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S02-4000-08L	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S02-4000-10L	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S02-4800-06L	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S02-4800-07L	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S02-4800-08L	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S02-5200-04L	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S02-5200-05L	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-0900-06a	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-0900-06-b	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-0900-07a	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-0900-07-b	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-1190-04	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-1190-05	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-1200-04a	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-1200-04-b	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-1200-05a	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-1200-05-b	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-1500-04-b	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-1500-05-b	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-1500-06-b	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-1500-07-b	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-1900-08a	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-1900-08-b	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-2000-04-b	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-2000-05-b	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-2000-06-b	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-2000-07-b	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-2050-05a	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-2050-05-b	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-2050-06a	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-2050-06-b	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-2050-07a	DCS800-S 000000	Boards, Control Units, Power Supplies
DCS800-S01-2050-07-b	DCS800-S 000000	Boards, Control Units, Power Supplies



Product	Category	所属分类
DCS800-S02-2050-07-b	DCS800-S 变频器	Boards, Control Units, Power Supplies
DCS800-S02-2050-10-b	DCS800-S 变频器	Boards, Control Units, Power Supplies
DCS800-S02-2500-04-b	DCS800-S 变频器	Boards, Control Units, Power Supplies
DCS800-S02-2500-05-b	DCS800-S 变频器	Boards, Control Units, Power Supplies
DCS800-S02-2500-06-b	DCS800-S 变频器	Boards, Control Units, Power Supplies
DCS800-S02-2500-07-b	DCS800-S 变频器	Boards, Control Units, Power Supplies
DCS800-S02-2500-08-b	DCS800-S 变频器	Boards, Control Units, Power Supplies
DCS800-S02-2600-10-b	DCS800-S 变频器	Boards, Control Units, Power Supplies
DCS800-S02-3000-04-b	DCS800-S 变频器	Boards, Control Units, Power Supplies
DCS800-S02-3000-05-b	DCS800-S 变频器	Boards, Control Units, Power Supplies
DCS800-S02-3000-06-b	DCS800-S 变频器	Boards, Control Units, Power Supplies
DCS800-S02-3000-07-b	DCS800-S 变频器	Boards, Control Units, Power Supplies
DCS800-S02-3000-08-b	DCS800-S 变频器	Boards, Control Units, Power Supplies
DCS800-S02-3300-04-b	DCS800-S 变频器	Boards, Control Units, Power Supplies
DCS800-S02-3300-05-b	DCS800-S 变频器	Boards, Control Units, Power Supplies
DCS800-S02-3300-06-b	DCS800-S 变频器	Boards, Control Units, Power Supplies
DCS800-S02-3300-07-b	DCS800-S 变频器	Boards, Control Units, Power Supplies
DCS800-S02-3300-08-b	DCS800-S 变频器	Boards, Control Units, Power Supplies
DCS800-S02-3300-10-b	DCS800-S 变频器	Boards, Control Units, Power Supplies
DCS800-S02-4000-04-b	DCS800-S 变频器	Boards, Control Units, Power Supplies
DCS800-S02-4000-05-b	DCS800-S 变频器	Boards, Control Units, Power Supplies
DCS800-S02-4000-06-b	DCS800-S 变频器	Boards, Control Units, Power Supplies
DCS800-S02-4000-07-b	DCS800-S 变频器	Boards, Control Units, Power Supplies
DCS800-S02-4000-08-b	DCS800-S 变频器	Boards, Control Units, Power Supplies
DCS800-S02-4000-10-b	DCS800-S 变频器	Boards, Control Units, Power Supplies
DCS800-S02-4800-06-b	DCS800-S 变频器	Boards, Control Units, Power Supplies
DCS800-S02-4800-07-b	DCS800-S 变频器	Boards, Control Units, Power Supplies
DCS800-S02-4800-08-b	DCS800-S 变频器	Boards, Control Units, Power Supplies
DCS800-S02-5200-04-b	DCS800-S 变频器	Boards, Control Units, Power Supplies
DCS800-S02-5200-05-b	DCS800-S 变频器	Boards, Control Units, Power Supplies

分类

传动 → 直流传动 → 工业传动 → 改造解决方案 → DCS800-R 维修套件  
传动 → 直流传动 → 工业传动 → 模块化工业传动 → DCS800-S 变流器模块

